

How to use the Epsilon fit guide


1.

Select the correct file based on appropriate size of Epsilon anchor (if you will fit the optional roll bar, select that file)




2.

Print the file at 100% to the paper size available.



3.

Once printed check the square guide to ensure the scale has remained in tact.



4.

Cut and join the pages together carefully, stick to cardboard for a more rigid guide.



5.

Offer the guide up with the shank between the bow rollers, to ensure suitability.

